

1000 Series Remote Commands

All Commands are subject to change to accommodate improved functionality.

All commands followed by Carriage Return or Line Feed (ASCII 13 or 10) or both.

Replies:

Commands (excluding Reading commands) will give a response code.

Successful commands are followed by *0<cr><lf>.

Unrecognised commands are followed by *1<cr><lf>.

Commands with incorrect range are followed by *2<cr><lf>.

Commands with incorrect frequency are followed by *3<cr><lf>.

Commands with incorrect output values are followed by *4<cr><lf>.

Commands with incorrect calibration factors are followed by *5<cr><lf>.

Unauthorised commands are followed by *6<cr><lf>.

Correct commands with incorrect parameters are followed by *7<cr><lf>.

Overtemperature Error is *8<cr><lf>.

Output Error is *9<cr><lf>.

Command words are separated by a colon. A space is required between the command words and the parameters. Command words are not case sensitive.

| Command | Format | Parameters |
|-------------------------|--|---|
| Transmit Reading | READ? | Only in: Adapter read-back ranges, Workstation Measure ranges |
| Set Output, autorange | o<value><prefix><unit> | <value> output value, defaults to current range units. <prefix> scales unit value, defaults to current range scale factor n u m k M <unit> defaults to current range units V - Voltage A - Current R - Resistance F - Capacitance H - Inductance |
| Set range | r<value> | <value> = 1-149 Allowed ranges dependent on selected options |
| Select AC Voltage Range | RANGE:AC:VOLTAGE<space> <value>,<accuracy> RANGE:AC:VOLT<space> <value> | value = 0.01 to 1000 Volts accuracy = 4-8 digits displayed |
| Select DC Voltage Range | RANGE:DC:VOLTAGE<space> <value> RANGE:DC:VOLT <space><value> | value = 0.1 to 1000 |
| Select AC Current Range | RANGE:AC:CURRENT <space><value> RANGE:AC:CURR<space> <value> | value = 10 ⁻⁴ to 30 |

| | | |
|--|---|--|
| Select DC Current Range | RANGE:DC:CURRENT <space><value> RANGE:DC:CURR<space> <value> | value = 10^{-8} to 30 |
| | | |
| | | |
| | | |
| Select 2-Wire Resistance (previously selected measurement current) | RANGE:RES <space><value> RANGE:RESISTANCE <space><value> | value=1 to 10^{12} |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| Enter Workstation Mode | MODE:WORKSTATION 1 | |
| Leave Workstation Mode | MODE:WORKSTATION 0 | |
| | | |
| | | |
| | | |
| Enter unlock code response | SYSTEM:UNLOCK <code> | code = unlock response Instrument will reboot to validate |
| Select adapter mode | adAPTERmode <n> | 0=off |
| Select adapter subrange | adAPTERrange <n> | |
| Select adapter subrange - autorange | adAPTERrange a | |
| Adapter set zero | MODE:SETZERO | |
| Thermocouple Cold Junction : Manual (3000a) | KT<temp> | <temp> = -50 to 100 °C |
| Set Active PRT R0 | PRTRZERO <resistance> | resistance = 25 to 1000 ohm |
| Select Active PRT | r95 | |
| | | |
| | | |
| | | |
| | | |
| Reset to startup state | *RST | Returns to 200mV range and clears state |
| Reboot calibrator | SYSTEM:REBOOT | Processor reset |
| Reset to starting state | *RST | System state reset |
| Debug mode On | debug 1 | Prints PWM Calculation |
| Debug mode Off | debug 0 | |
| Identification String | *IDN? | |
| | | |

TDS Compatible

| Command | Format | Parameters / Notes |
|---------|--------|--------------------|
| | | |
| | | |
| | | |
| | | |

| | | |
|---|--------------|---|
| | | |
| | | |
| | | |
| | | |
| | | |
| Set Frequency | F <value> | <i>value</i> : allowed values depend on instrument specification |
| | | |
| PWM preset | H<index> | index=0-8: 10%,20%,30%,40%,50%,60%, 70%,80%,90% |
| Frequency Range: presets | H<index> | index=0-11: 1,10,100,1k,10k,20k,50k,100k, ,300k,500k,1M,10M |
| Frequency Range: variable | O<frequency> | frequency=1 up to 1000000 or 10000000 |
| | | |
| 2-wire Resistance | I0 | |
| | | |
| Active Resistance | I2 | |
| | | |
| Thermocouple Cold Junction : Manual Zero | K0 | |
| Thermocouple Cold Junction : Auto | K1 | |
| Thermocouple Cold Junction : Manual (3000a) | KT<temp> | <temp> = -50 to 100 °C |
| Thermocouple Type | L<type> | <type> = {1,2,3,4,5,6,7,8} |
| Thermocouple Type (3000a) | L<type> | <type> = {K,J,T,R,S,E,N,B} |
| Power: Set Phase | M<phase> | <phase> = 0.0 to 359.9° |
| Calibration: set negative cal factor | N<calfactor> | <calfactor> range-dependent |
| Set Output, locked to current range | O<value> | <value> range-dependent, specified in range units. |
| Calibration: set positive cal factor | P<calfactor> | <calfactor> range-dependent |
| Set Range (TDS compatible ranges) | R<range> | <range> = 1 to 79 |
| Standby Off | S0 | No space |
| Standby On | S1 | |
| Print Version Information | T | reply: Firmware Version Initialise Version (Always 1.0) Model Date Time *0 |
| Print Option Information | U | reply: (16 char strings) Model Options 1 Options 2 Serial Cal Date Cal Due Cal Period Cert No |

| | | |
|---|--------------|---|
| | | Spare Spare Address Prev Cal Date Prev Cert No Prev Cal Date 2 Prev Cert No 2 |
| Print Cal Factors | V | For TDS Compatibility only |
| Print R/C/Ind Cal Factors | W | For TDS Compatibility only |
| Print displayed reading | X | reply: Primary Display Text Frequency *0 |
| Print displayed reading (on 1Gohm Range) | X | reply: Value in MOhms 0 *0 |
| Transmit Calibration Factors for current range (TDS-compatible) | Y | reply: Positive factor Negative factor Zero factor Misc. factor *0 Except for the ranges below: DC: P N Z AC: P N Z 40* Frequency Points 1-20 interleaved with 21-25 Resistance: P N Active Zero Active FS Ind/Cap: P N Z Scope BW 5-600MHz: 30* 32-bit Pairs at 20MHz intervals treat 5 as 0 Low 16-bits = n MHz High 16-bits = n+10 MHz Scope Amplitude: P P P P In power Mode (AC or DC): P N Z 20*FrequencyPoints |
| Calibration: set zero cal factor | Z<calfactor> | <calfactor> range-dependent |

| | | |
|--|--------------------------|---|
| | | |
| Start Calibration | a1 | Allows calibration changes (indicated by shift LED) |
| Store Calibration | a2 | Stores changes to current range in EEPROM |
| Abort Calibration | a0 | Reloads values from EEPROM |
| | | |
| Output Error Disable Off | e0 | |
| Output Error Disable On | e1 | |
| | | |
| Local Mode | l | |
| Set pod relays | p<value> | <value> 24 bits as decimal: bits 0-7 = Pod 1 Relays 1-8 bits 8-15 = Pod 2 Relays 1-8 bits 16-23 = Pod 3 Relays 1-8 If any bits 24-31 are set, latch will not be strobed. |
| Read adapter A/D input | v | reply: Voltage in μ V *0 |
| | | |
| Reset calibration factors for current range to default | x | Must be in cal mode |
| Store Information explain behaviours | &<Address> <Information> | Address = 2 digits {00-20} Information = string up to 20 characters |
| | | |
| | | |
| | | |
| Display Fullscreen Message | #<text> | |
| Clear Fullscreen Message | # | |

Setup

| Command | Format | Parameters |
|-----------------------|--|---|
| Set D/A Low Bits | d_lowbits <n> | n=-3519 to +3519 |
| Set D/A Mid Bits | d_lowbits <n> | n=0 to 249 |
| Set D/A High Bits | d_lowbits <n> d_vco1 <f> d_vco1 <f> d_powerda <n> | n=0 to 249 |
| | d_phasesetp <n> | |
| | d_setdds <f> | |
| | d_arada <n> | |
| | d_setlatch <latch>,<value> | |
| | d_scopelatch <latch>,<value> | |
| | | |
| Set range description | MODE:TITLE <text> | text = string up to 20 characters. Underscore is displayed as space |

| | | |
|---|-----------------------|--|
| | | |
| Read range description | MODE:TITLE <range> ? | range = 135-144 |
| Set range unit | MODE:UNIT <text> | |
| Read range unit | MODE:UNIT <range> ? | |
| Set number of decimal places displayed | MODE:SETDP <n> | n=0-6 |
| Calibrate A/D converter negative, zero, positive. | MODE:ADCAL <measured> | Measured value must be close to nominal values -10, 0, +10 |
| | | |

Calibration

Commands that change the calibration memory require the correct calibration password to be sent.

| | | |
|--------------------------|-------------------|--|
| Show Calibration History | CALIBRATE:HISTORY | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Frequency Limits

| Range | Min | Max |
|-------|--|---|
| 200mV | 10Hz | 3010,3041: 500kHz 3050: 20kHz |
| 2V | 10Hz | 3010: 1MHz 3041: 500kHz 3050: 100kHz |
| 20V | 10Hz | 100kHz |
| 200V | 3010,3014: 30Hz 3050: 40Hz | 3010: 40kHz 3050,3041: 20kHz |
| 1kV | Up to 710V 3010,3014: 30Hz 3050: 40Hz Up to 1kV: 46Hz | 3010,3041: 40kHz up to 350V 35kHz up to 450V 20kHz up to 710V 10kHz up to 1kV 3050: 10kHz all voltages |
| 200uA | 10Hz | 10kHz |
| 2mA | 10Hz | 10kHz |
| 20mA | 10Hz | 10kHz |
| 200mA | 10Hz | 10kHz |
| 2A | 10Hz | 5kHz |
| 30A | 10Hz | 1kHz |

Calibration Points

AC Calibration Frequencies

Main full-scale and zero calibration at 206Hz.

Additional full-scale calibration at the following frequencies:

10,30,56,106,206,596,1000,2000,3500,5000,7500,10000,15000,20000,30000,40000,50000,60000,80000,100000,200000,400000,500000,750000,1000000;
Except 3050: 40Hz point replaces 30Hz.

Resistance Limits

| | Low | High |
|------------|------|------|
| 1% default | | |
| 0R | .160 | .220 |
| 0.1R | .260 | .320 |
| 1R | 1.15 | 1.3 |

| | | |
|------------|------|-------|
| 10R | 10 | 10.4 |
| 100R | 100 | 100.4 |
| 1kR | 990 | 1010 |
| 10kR | 9.9k | 10.1k |
| 100kR | 99k | 101k |
| 1MR | 990k | 1010k |
| 10MR | 9.9M | 10.1M |
| 100MR | 99M | 101M |
| 1GR | 950M | 1050M |
| 4-wire | | |
| 0R | 0 | |
| 0.1R | 0.09 | 0.11 |
| 1R | .95 | 1.05 |
| 10R | 9.8 | 10.2 |
| 100R | 99 | 101 |
| 1kR | 990 | 1010 |
| 10kR | 9.9k | 10.1k |
| 100kR | 99k | 101k |
| | | |
| | | |
| | | |
| 5% default | | |
| 1nF | 1.01 | 1.12 |
| 10nF | 9.5 | 10.5 |
| 20nF | | |
| 50nF | | |
| 100nF | 95 | 105 |
| 1uF | 950 | 1050 |
| 10uF | 9.5 | 10.5 |
| 100uF | 95 | 105 |
| 1mF | | |
| 10mF | | |
| 100mF | | |
| 10% | | |
| 1mH | | |
| 10m | | |
| 19m | | |
| 29m | | |
| 50m | | |
| 100m | | |
| 1 | | |
| 10 | | |
| | | |
| | | |
| | | |

Procedure Commands

| Command | Format | Parameters |
|-------------------|---|--|
| Read Title | proc_title <number> ? | number=1-10 |
| Set Title | proc_title <number>,<title> | title = string |
| Read Test Details | proc_test <number>,<test> ? Returns 5 lines: Nominal decimal point location Function Tolerance High Tolerance Low | |
| Set Test Details | proc_test <number>,<test>,<nominal>,<decimal>,<function>,<tolerance_high>,<tolerance_low> | <number> = procedure 1-10 <test> = test number 0-50 <nominal> = test nominal value (integer) <decimal> = decimal point location <function> = 1 : voltage 2 : current 3 : resistance <tolerance_high> <tolerance_low> floating-point value, maximum deviation from nominal |
| Example | proc_test 1,1,1234,3,1,0.001,0.001 | Set procedure 1 test 1 to 1.234 V +-1mV |